





Profilfaktoren A_m/V und A_p/V in $[m^{-1}]$

Profilfaktoren für die Berechnung des Feuerwiderstandes

Facteurs de massivité A_m/V et A_p/V en $[m^{-1}]$

Facteurs utilisés en calcul de résistance au feu

HEM				
-----	---	---	---	---

HEM 100	96	116	65	85
HEM 120	92	111	61	80
HEM 140	88	106	58	76
HEM 160	83	100	54	71
HEM 180	80	96	52	68
HEM 200	76	92	49	65
HEM 220	73	88	47	62
HEM 240	61	73	39	52
HEM 260	59	72	39	51
HEM 280	59	71	38	50
HEM 300	50	60	33	43
HEM 320	50	60	33	43
HEM 340	50	60	34	43
HEM 360	51	61	34	44
HEM 400	52	62	36	45
HEM 450	53	62	38	47
HEM 500	55	63	39	48
HEM 550	56	64	41	50
HEM 600	57	65	42	51
HEM 650	58	66	44	52
HEM 700	59	67	45	53
HEM 800	60	68	48	55
HEM 900	62	69	50	57
HEM 1000	64	70	52	59