





Profilfaktoren A_m/V und A_p/V in $[m^{-1}]$

Profilfaktoren für die Berechnung des Feuerwiderstandes

Facteurs de massivité A_m/V et A_p/V en $[m^{-1}]$

Facteurs utilisés en calcul de résistance au feu

| | | | | |
|-----|---|---|---|---|
| UNP |  |  |  |  |
|-----|---|---|---|---|

| | | | | |
|---------|-----|-----|-----|-----|
| UNP 65 | 256 | 302 | 190 | 237 |
| UNP 80 | 242 | 283 | 186 | 227 |
| UNP 100 | 239 | 276 | 185 | 222 |
| UNP 120 | 223 | 255 | 174 | 206 |
| UNP 140 | 210 | 240 | 167 | 196 |
| UNP 160 | 200 | 228 | 160 | 188 |
| UNP 180 | 193 | 218 | 154 | 179 |
| UNP 200 | 182 | 205 | 148 | 171 |
| UNP 220 | 171 | 192 | 139 | 160 |
| UNP 240 | 163 | 183 | 134 | 154 |
| UNP 260 | 154 | 173 | 126 | 145 |
| UNP 280 | 149 | 167 | 123 | 141 |
| UNP 300 | 145 | 162 | 119 | 136 |
| UNP 320 | 116 | 130 | 98 | 111 |
| UNP 350 | 123 | 135 | 103 | 116 |
| UNP 380 | 125 | 138 | 107 | 120 |
| UNP 400 | 117 | 129 | 99 | 111 |